




Eltron (Zebra) LP 2824 – Settings for Windows Vista, Server 2003 and 7

1. Right click printer Eltron LP 2824 och choose "Properties" -> "Printing Preferences".



2. b For paper labels (P500 and P200), please apply the settings below:



3. För labels with adhesive (E200), please apply the settings below:

